



Bâti
Frame



	6	9	19	23	25	26	28
Ref.	7531 31	7531 32	7531 33	7531 34	7531 35	7531 36	7531 37


	30	36	37	38 (set of 4)	39	45
Ref.	7531 38	7531 39	7531 40	7530 67	7531 41	7531 42

Chariot Carriage




	6	15	18
Ref.	7531 51	7531 52	7531 53

Coupe tube
Pipe cutter



	1	7	10	11	12	16	17
Ref.	7531 54	7531 55	1624 70 Acier/Steel 1624 71 Stainless steel	7531 56	7531 57	7531 58	7530 72

Ebavureur
Reamer



	1	4	9	12
Ref.	7530 74	7531 59	7530 75	7531 60




Motor and pump

This exploded view diagram illustrates the assembly of a motor and pump unit. The components are numbered 1 through 49. The assembly is organized into five main sections labeled A, B, C, D, and E.

- Section A:** Includes the motor housing (1), end cap (2), and various fasteners (3, 4, 5, 6, 7, 8, 9, 10, 11).
- Section B:** Features the motor winding (12), terminal block (13), and associated wiring (14, 15, 16, 17, 18, 19).
- Section C:** Shows the pump housing (20), impeller (21), and various seals and fasteners (22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49).
- Section D:** Includes the pump housing (20), impeller (21), and various seals and fasteners (22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49).
- Section E:** Shows the pump housing (20), impeller (21), and various seals and fasteners (22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49).

	12	17	18	49
Ref.	7531 27	7531 28	7531 29	7531 30

Tête 1/2 à 2"
1/2 to 2" dies head



	8	9	11	17
Ref.	7531 16	7531 17	7531 18	7531 19

	18	20	38
Ref.	7531 20	7531 21	1621 51




virax

Machine à fileter 2"
2" threading machine

1621 20

Transmission **Transmission**



	1	2	20	21	31 (set of 3)
Ref.	7531 43	7531 44	7531 45	7531 46	7530 69
	35	36	38	39 (set of 3)	
Ref.	7531 47	7531 48	7531 49	7530 68	